


OOKI DINING TABLE


Saveri™

ASSEMBLY INSTRUCTION

PART LIST



A (4X)




B (2X)




C (1X)




D (8X)




E (1X)




F (1X)



G (1X)



ASSEMBLY





STEP 1

OOKI DINING TABLE

ASSEMBLY INSTRUCTION

Saveri™






STEP 3

OOKI DINING TABLE

ASSEMBLY INSTRUCTION

SaVeri™

STEP 4



STEP 5

